


ITC 

A VERDER COMPANY



DOSmart

MANUAL

ENGLISH

CONTENTS

1 GENERAL DESCRIPTION	6
2 PACKING AND STORAGE	7
2.1. WASTE DISPOSAL	7
3 TECHNICAL SPECIFICATIONS	8
FLOW AND PRESSURE GRAPHS	10
4 INSTALLATION	11
4.1 GENERAL	11
4.2 WIRING	12
4.3 HYDRAULIC INSTALLATION	14
4.3.1 Installation examples	14
4.3.2 Installation recommendations	15
4.4 ACCESSORIES	16
4.4.1 Multifunction Valve	16
4.4.2 Automatic Degassing Head	16
4.4.3 Diaphragm leakage detector (DOSmart AC)	17
4.4.4 Pressure sensor (DOSmart AC)	17
5 OPERATION	18
6 USO Y CONFIGURACIÓN DOSMART AC	19
6.1 OPERATING MODES	21
6.1.1 Manual mode	21
6.1.2 Proportional mode	21
6.1.3 Analogue mode	23
6.1.4 Batch dosing mode	24
6.2 CONFIGURATION	27
6.2.1 Pump calibration	27
6.2.2 Dosing mode	27
6.2.3 Configuration	29
6.2.4 Inputs/outputs	33

6.3 ALARMS	35
6.3.1 Level alarm 1	35
6.3.2 Level alarm 2	35
6.3.3 Flow fault alarm	36
6.3.4 Diaphragm leakage alarm	37
6.3.5 Overpressure alarm	37
6.4 MONITOR	38
6.4.1 Real time	38
6.4.2 Counters	38
6.4.3 Info Unit	39
7 USO Y CONFIGURACIÓN DOSMART BC	40
7.1 OPERATING MODES	41
7.1.1 Manual Mode	41
7.1.2 Pulse Mode (X:Y)	42
7.1.3 Check Info Mode	43
8 Special functions (AC & BC)	44
8.1 Remote activation	44
9 START-UP AND REGULATION	45
10 MAINTENANCE	46
Spare parts	46
Periodic Maintenance:	50
Troubleshooting: Possible cause and solution	51
Wiring	53
CE DECLARATION OF CONFORMITY	55
WARRANTY	55



SAFETY INSTRUCTIONS

To avoid personal injury risks and damage to the environment, and to ensure proper equipment operation, personnel responsible for installing, commissioning and maintaining the equipment must follow the instructions in this manual, with special attention to the detailed recommendations and warnings. The specific instructions for the use of the chemicals to be dosed must also be followed.

This appliance must not be used by people (including children) with reduced physical, sensory or mental abilities or who lack experience and knowledge, unless they have received supervision or instruction. Children should not play with the appliance unsupervised.

1 GENERAL DESCRIPTION

DOSmart is a range of stepper motor-driven dosing pumps designed to automate the precise and efficient dosing of liquid chemicals.

These pumps are known for their high accuracy, wide adjustability, and strong suction capacity—even when handling viscous fluids. The flow rate range meets dosing requirements from 1.5 to 60 l/h, with pressure up to 16 bar.

Selecting the appropriate pump head material—PP, PVDF or stainless steel—allows safe and effective dosing of most chemicals commonly used in water treatment, the chemical industry, food processing, and agriculture.

Operating modes

Manual: Flow rate adjusted manually via the keypad.

Flow proportional: Dosing rate is proportional to a water flow signal

AC only:

Analogue: Dosing rate is proportional to an analogue input signal (0/4–20 mA).

Pulse proportional: Dosing is controlled by input pulses; dosing cycles are proportional to pulse frequency.


Batch dosing (by volume): Delivers a defined volume. Can be triggered manually, remotely, or on a timer.

Timed dosing: Delivers dosing over a preset time period. Can be triggered manually, remotely, or on a timer.

ModBus: Dosing control via ModBus RTU protocol.

ModBus: control de la dosificación a través del protocolo ModBus RTU.

Code formulation



Pulse Frequency

The DOSmart pump accepts pulse input signals to externally control the dosing flow rate. The supported input frequency ranges are as follows:

- AC model: accepts input frequencies from 0.005 Hz to 300 Hz.
- BC model: allows input frequencies from 0 Hz up to 500 Hz.

This wide operating range provides flexibility to meet various control requirements, ensuring accurate and stable dosing at all times.

2 PACKING AND STORAGE

The original packaging is designed to allow the equipment to be transported and stored without damage, provided this takes place in dry, ventilated spaces away from heat sources.

Included in the packaging are:

- DOSmart AC dosing pump
- Instruction manual
- Connection accessories for 4 x 6, 6 x 8, 6 x 12, 10 x 12 conduit

2.1. WASTE DISPOSAL



This equipment is labeled with the crossed-out waste container symbol in accordance with the European Directive 2012/19/EU on Waste Electrical and Electronic Equipment. Do not dispose of the device with household waste. For proper disposal, use the available collection and recycling points and follow the applicable local regulations.

It is the owner's responsibility to manage the equipment as waste in accordance with the current regulations in the country of use at the end of its useful life.

3 TECHNICAL SPECIFICATIONS

STA... / STD ...		S50-D50	F50-D50	F30-D50	F50-D69	F30-D69	F41-D69	F31-D69
Flow max. at P max.	l/h	1,5	4	8	12	24	40	60
	gph	0,40	1,05	2,10	3,15	6,30	10,50	15,80
Max. pressure	bar	16	12	8	7	5	3	2
	psi	232	174	116	100	72	44	29
Diaphragm diameter	mm	50	50	50	69	69	69	69
Stroke	mm	2	2	2	2	2	4,5	4,5
Cycles/min		40	82	143	85	164	113	164
Volume/cycle at Pmax	ml	0,63	0,82	0,93	2,36	2,44	5,92	6,08
Adjustment range	(AC)	1:3000	1:3000	1:3000	1:3000	1:3000	1:3000	1:3000
	(BC)	1:1000	1:1000	1:1000	1:1000	1:1000	1:1000	1:1000
Minimum flow	ml/h	0,50	1,34	2,66	4,00	8,00	13,33	20,00
	gpd	0,0032	0,0085	0,0169	0,0254	0,0507	0,0845	0,1268
Slow suction max. flow 75% (AC)	l/h	1,12	3	6	9	18	30	45
	gph	0,30	0,79	1,59	2,36	4,73	7,94	11,90
Slow suction max. flow 50% (AC)	ml/h	0,75	2	4	6	12	20	30
	gph	0,20	0,53	1,06	1,56	3,15	5,29	7,94
Max. suction head in operation	m	6	6	6	5	5	5	3
Max. suction head, priming with empty head	m	2	2	2	1,5	1,5	3	3
Max. viscosity, std. valve (and minimum DN pipe)	mPa.s	100	10	200	100	200	200	100
Max. viscosity, M valve with spring (and DN15 pipe)	mPa.s	3000	3000	3000	3000	2100	2000	600
Max. viscosity, M valve SS1 with spring (and DN15 pipe)	mPa.s	3000	3000	3000	3000	3000	3000	1800
Max. viscosity, M valve SS2 with spring (and DN15 pipe)	mPa.s	3000	3000	3000	3000	3000	3000	1800
Valve connections		4x6	4x6	6x8/6x12	6x8/6x12	10x12	10x12	10x12
Recommended minimum pipe DN (water and up to L=2 m)	mm	4	4	6	6	10	10	10
SUC L=2m	mm	4	4	6	6	10	10	15
SUC L=5m	mm	4	4	10	10	15	15	20
P max. suction	bar	1	1	1	1	1	1	1
Ambient T max.	C/F	0...45 C / 32...113 F						
T max. average	C/F	PP: 0...50C / 32...122 F; PVDF: -10...50C / 14...122 F; -10...60 / 14...140 F; AISI316:						
Relative humidity max.:		95% (without condensation)						
Noise level	dB(A)	< 60						
Protection		IP65						
Weight	Kg	4,5 kg / 10 lb						
Voltage	V	100-250 Vac / 22-30 Vdc						
Frequency	Hz	50/60 Hz						
Power	W	32						
Current	A	0,14 A (230 Vac) / 0,24 A (110 Vac) / 1 A (24 Vdc)						

Inputs

- Analogue input 0/4–20 mA
- Level sensor input (pre-alarm)
- Leak detector input
- Flow sensor input
- Pressure sensor input
- RS-485 ModBus serial port
- External pulse input
- Remote start/stop input (on/off)
- Level sensor input (alarm)

BC

AC


- | | |
|---|---|
| X | ✓ |
| X | ✓ |
| X | ✓ |
| X | ✓ |
| X | ✓ |
| X | ✓ |
| ✓ | ✓ |
| ✓ | ✓ |
| ✓ | ✓ |

Outputs

- 4–20 mA output for monitoring and logging
- Pulse output for logging, monitoring and controlling a second pump
- Alarm output (relay)
- Level alarm output (relay)








- | | |
|---|---|
| X | ✓ |
| X | ✓ |
| X | ✓ |
| X | ✓ |

DIMENSIONS



FLOW AND PRESSURE GRAPHS

- Pressure compensation activated
- - - - Pressure compensation deactivated



4 INSTALLATION


4.1 GENERAL

It should be installed in a place protected from water, away from heat sources and with renovation of air.

Fix the pump on a rigid horizontal surface. Provide enough space to comfortably perform basic maintenance and facilitate installation and removal.

Fix the pump to the chosen flat surface using 4 screws

(See drawing).



4.2 WIRING



The electrical protection of the motor must be installed and adjusted on the basis of its nominal current (thermomagnetic circuit breaker). (See connection).


A device for disconnection in case of emergency must be installed.

The equipment must be protected against false starts.

If the power cord is damaged, it must be replaced by the manufacturer, by its after-sales service or by similar qualified personnel in order to avoid any hazard.

STA : 110-250V AC

STD : 24V dc



DOSmart BC WIRING


N	FUNCTION	DETAIL
Inputs	Proportional pulse input	Pulses
	Proportional pulse input	(-)
	Remote	Voltage free contact
	Remote	Voltage free contact
	Level sensor 1	Voltage free contact
	Common level sensor	Voltage free contact

DOSmart AC WIRING

N	FUNCTION	DETAIL
Inputs		
1	Encoder	+12 Vdc
2	Encoder	F1
3	Encoder	F2
4	Encoder	S
5	Encoder	(-)
6	Flow detector	(+)
7	Flow detector	(-)
8	Leakage detector	(+)
9	Leakage detector	(-)
10	Pressure transmitter	+24 Vdc
11	Pressure transmitter	(+)
12	Pressure transmitter	(-)
13	4-20 mA input analogue mode	(+)
14	4-20 mA input analogue mode	(-)
15	Proportional pulse input (flow meter / counter)	Pulses
16	Proportional pulse input (flow meter / counter)	(-)
17	Remote	Voltage free contact
18	Remote	Voltage free contact
19	Level sensor 1	Voltage free contact
21	Level sensor 2	Voltage free contact
22	Common level sensor	Voltage free contact
Outputs		
33	RS-485	+5 Vdc
34	RS-485	H (B)
35	RS-485	L (A)
36	RS-485	(-)
37	4-20 mA monitor output	(+) Not isolated
38	4-20 mA monitor output	(-) Not isolated
39	Monitor pulse output	Isolated signal
40	Monitor pulse output	(-) isolated
41	Level alarm 2 output	NO
42	Level alarm 2 output	NC
43	Level alarm 2 output	Common (max. 5 A 250 V ac)
44	Alarm output	NO
45	Alarm output	NC
46	Alarm output	Common (max. 5 A 250 V ac)

4.3 HYDRAULIC INSTALLATION

4.3.1 Installation examples




- ⚠ 1. To avoid undissolved particles, never suck the product to be injected from the bottom of the tank.
- ⚠ 2. Filter. It is essential to install a filter (150 micron) in the suction piping.
- 3. Level sensor
- 4. Agitator
- ⚠ 5. Make sure to connect a hose or pipe made of material compatible with the product dosed to the bottom of the cylinder at the drain hole in case of a rupture of the membrane and collect the liquid in a safe place.
- 6. Priming and drain valve built into the pump.
- ⚠ 7. Pressure relief valve. Install a pressure relief valve in a bypass as close as possible to the pump in order to protect the pump and the installation from possible overpressure. This bypass should pipe the liquid to a safe place.
- 8. Pulse dampener
- 9. Pressure gauge.
- 10. Pressure maintenance valve.
- 11. Flowmeter
- ⚠ 12. Injection check valve


4.3.2 Installation recommendations

SUCTION

⚠ Long suction: $L > 2$ m (6.5 ft)




⚠ Air in suction




DISCHARGE

⚠ Long discharge: $L > 5$ m (16 ft)



⚠ Siphon




4.4 ACCESSORIES

4.4.1 Multifunction Valve

The multifunction valve is designed for use with DOSmart pumps and combines five functions into a single accessory: pressure sustaining valve, safety valve, priming valve, non-return valve, and anti-siphon valve. Its integration enhances the safety and stability of the DOSmart dosing system, especially in installations with pressure fluctuations.

It is available for flow rates up to 60 l/h and features 3/4" L-type inlet connections. Manufactured in PVDF, with seals in various materials (EPDM, FPM, or TFE/P), it is compatible with a wide range of chemicals.


Pressure Sustaining	Code
2-8 bar ± 0.5	18-019
1-2 bar ± 0.5	18-020



4.4.2 Automatic Degassing Head

The automatic degassing head allows continuous evacuation of air or gas bubbles from the hydraulic circuit, preventing interruptions in dosing.

Designed for use with DOSmart pumps, it is available in polypropylene (PP) and PVDF versions, and supports flow rates up to 60 l/h.



- ① SUCTION FILTER
- ② SUCTION TUBING
- ③ GAS OUTLET
- ④ INJECTION TUBING
- ⑤ INJECTION VALVE


Construction Material	Code
Polipropileno (PP)	18-028-P
PVDF	18-028-F

4.4.3 Diaphragm leakage detector (DOSmart AC)

The diaphragm leakage detector is an electrical conductivity sensor capable of detecting the presence of liquid when its conductivity is 0.05 mS or higher. The pump must be provided with the specific diaphragm flange for housing the detector.

Diaphragm Ø	Diaphragm leakage sensor kit
50	29-068-P
69	29-063-P

Fit the detector Ref. 29-056 in the lower opening of the diaphragm and connect pins 8 - 9 as shown in the drawing.




4.4.4 Pressure sensor (DOSmart AC)

The pressure sensor protects the pump from working in overpressure conditions, when the pressure alarm is activated. Connect the 4 - 20 mA 10 bar pressure sensor Ref. 18705 as shown in the drawing.

PRESSURE


24 + -
10 11 12




5 OPERATION

The electric motor transmits power via a reducer, consisting of a pinion (A) and an eccentric crown (B) that drives a connecting cam (C) onto which the diaphragm (D) is screwed. Spring (F) is compressed during the suction cycle, thus storing energy which is released during the delivery cycle.


By varying the speed of the motor and depending on the operating mode selected in the Control Unit, the equipment will regulate the flow to the desired value with a maximum variation of 1:3000.



EQUIPMENT DESCRIPTION




6 DOSMART AC USE AND CONFIGURATION



- Exit without confirming / **Ⓐ**
- Start / Stop / Enter (Validate)
- Increase/decrease value
- Decrease/increase value
- Scroll left
- Scroll right/test

LCD DISPLAY DESCRIPTION



Menu.s

6.1 Operating modes



- Manual
- Proportional
- Analogue
- Batch

6.2 Configuration



- Pump calibration
- Dosing Mode
 - Standard (ST)
 - Slow Suction 1 (SS1)
 - Slow Suction 2 (SS2)
- Set Up
 - Dosing pump
 - Units
 - Flowmeter
 - Lock code
 - ModBus
- In/Out
 - Pressure Input
 - Flow detector
 - Pulse output
 - 4-20 mA out
- Maintenance
 - Valves
 - Diaphragm
 - Bellows

6.3 Alarms



- Level 1
- Level 2
- Flow rate
- Leakage
- Pressure

6.4 Monitor





- Real time
 - Inputs
 - Outputs
 - Monitor motor
- Counters
- Info
- Unit

6.1 OPERATING MODES

6.1.1 Manual mode

This mode allows manual adjustment of the dosing flow rate.





▲ ▼ Increase/decrease flow
 ● Start/stop the pump

The pump will start if the Remote Activation input is activated.

6.1.2 Proportional mode

This mode allows dosing to be proportional to a pulsed input. Use X:Y mode to establish a ratio of input pulses (X) to pump cycles (Y). Use the %/ppm mode for proportional dosing. Ajustes del modo proporcional



Proportional to a pulse input from a flowmeter
 1. X:Y for low frequency pulses (0,005-30 Hz)
 2. %/ppm for high frequency flowmeters (1-300 Hz)

6.1.2.1 X:Y pulses

The pump will cycle Y times after receiving X input pulses. The pump speed can be adjusted manually.




Select the number of input pulses

Change by pressing ▲ ▼ and confirm by pressing ●




Select the number of pump cycles

Change by pressing and validate by pressing



Select pump speed in %

Change by pressing and confirm by pressing
For Y=1 Q must be set at less than 50%



Select the maximum number of pulses in memory


Change by pressing and confirm by pressing



Start/stop the pump
The pump will start if the Remote Activation input is activated.


6.1.2.2 %/ppm Flowmeter

By entering a proportion value (%/ppm) and with a pulse input from a flowmeter, the pump will regulate its speed to dose the flow according to the desired proportion.




Proportionality value in % or ppm

Change by pressing and confirm by pressing



Select OFF to perform proportional dosing with no volume limit.

Change by pressing and confirm by pressing




Instantaneous water flow rate

Pressing will cause the ON/OFF indicator to toggle to ON and the pump will start if the Remote Activation input of is activated

* For the configuration of units (%/ppm) see Units in the Configuration section

* For flowmeter configuration. See the Configuration/Setup section



Select ON to perform proportional dosing with a volume limit. The pump will stop when it reaches the ENT maximum volume to be dosed.

Change by pressing and confirm by pressing



Set the desired maximum volume.

Change by pressing and validate by pressing



Volume to be dosed


volume dosed

By pressing ENT the ON/OFF indicator will change to ON and the pump will start if the Remote Activation input is activated.


The pump will stop when it reaches the maximum volume set.

6.1.3 Analogue mode

This mode allows dosing proportional to an analogue 0/4-20 mA input.




6.1.3.1 Analogue mode configuration




Select mA input for the first point

Change by pressing and confirm by pressing



Select the flow in % for the first point in mA

Change by pressing and confirm by pressing



Select mA output for the second point
Change by pressing and confirm by pressing




Select the flow rate in % for the second point in mA
Change by pressing and confirm by pressing




Start/stop the pump
The pump will start if the Remote Activation input is activated

Examples:


1: 4 mA=0%
20 mA=100%




2: 4 mA=100%
20 mA= 0%



3: 4 mA=0%
12 mA= 100%




4: 12 mA=0%
20 mA= 100%



Examples 3 and 4 can be combined into two pumps when both are controlled with the same mA signal to start a second pump as supplementary flow.

6.1.4 Batch dosing mode

This mode allows batch dosing. Various activation options may be chosen (manual, external, time), and an end of the work cycle defined by number of cycles/volume or by time. In any of the operating modes, the speed of the pump can be defined in %.



Batch dosing mode settings

6.1.4.1 Select start-up mode

Start	Man.
Flow	000 %
Stop	Stroke

Manual: start the pump by pressing 

Start	Ext
Flow	000 %
Stop	Stroke

Ext.: start the pump via remote input

Start	Time
Flow	000 %
Stop	Stroke

Time: start the pump using a timer by entering a frequency (00:00:01-23:59:59)

6.1.4.2 Select stroke frequency in % (flow)

Start	Man.
Flow	050 %
Stop	Stroke

Change by pressing   and confirm by pressing 


6.1.4.3 Select stop mode

Start	Man.
Flow	050 %
Stop	Stroke


Stroke: select the number of cycles before stopping

Start	Man.
Flow	050 %
Stop	000050 St
Volume	208,15ml

Change by pressing   and confirm by pressing 






Time: set cycle execution time before stopping



Change by pressing and confirm by pressing

Viewing the different configuration modes



6.1.5.1 Priming function test

Press and hold the button for 3 seconds in manual mode to start the pump at maximum speed. The pump will continue running only while the button is pressed.


This function allows for a quick test of the unit and assists with priming the pump.

6.2 CONFIGURATION

6.2.1 Pump calibration


The pump calibration function allows the pump flow to be calibrated in real working conditions via a product suction test of a given duration. For a correct calibration, a test duration of at least 60 seconds must be entered. The pump will automatically start during the time of the test.

Once the test is finished, the suction volume must be entered. With this result the equipment will recalculate the dosing flow.



6.2.2 Dosing mode

The Dosing Mode function allows the various Advanced Dosing Functions to be selected. These functions can regulate the speed of the mechanism during the suction and delivery cycle of the pump in order to optimize the dosing and suit it to the characteristics of the process.



6.2.2.1 Low pulsation standard


The Standard ST mode is the normal operating mode where the doser has symmetrical behaviour during suction and delivery of the product while working at maximum capacity. As the flow rate is reduced, the delivery cycle is extended, keeping the suction duration constant.



100% operation




50% operation



Change by pressing ▲ ▼ and validate by pressing START/STOP

6.2.2.2 Slow suction SS1


The Slow Suction 1 (SS) mode reduces the speed during the suction cycle while increasing the pressure cycle to compensate for the loss of flow. In this way, the accuracy of the dosing of viscous liquids is improved, since the risk of cavitation and incomplete filling of the head is reduced. Suction is carried out at 50% of the speed of Standard mode, but the final flow is reduced to only 75%.



Change by pressing ▲ ▼ and validate by pressing START/STOP

6.2.2.3 Slow suction SS2

The Slow Suction 2 (SS) mode reduces the speed during the suction and delivery cycle. The suction operation is as described for Slow Suction 1, and the delivery cycle speed is also reduced to 50% to avoid overpressure in long deliveries. In this mode the flow is reduced to 50%




Change by pressing ▲ ▼ and validate by pressing START/STOP

6.2.3 Configuration

5.2.3.1 Dosing pump

Technical characteristics of the pump



Pump flow rate

Real Flow is the flow rate resulting from the calibration, if it has been performed. Max. Flow is the resulting flow according to the limit and/or selected dosing profile.

DOSING PUMP	
Flow	25.0 l/h
Flow max	12.5 l/h
Limit	100 %
Pres. Alm	05.0 Bar
Pres. Comp	Off

Limited flow %

This is the maximum limited flow of the pump. It limits the pump flow so that it does not exceed the entered value under any circumstances.

DOSING PUMP	
Flow	25.0 l/h
Flow max	12.5 l/h
Limit	100 %
Pres. Alm	05.0 Bar
Pres. Comp	Off

Change by pressing and confirm by pressing

Maximum pressure

Dosing pump maximum working pressure

DOSING PUMP	
Flow	25.0 l/h
Flow max	12.5 l/h
Limit	100 %
Pres. Alm	05.0 Bar
Pres. Comp	Off

Change by pressing and confirm by pressing

Compensation of working pressure


Flow compensation as a function of working pressure

DOSING PUMP	
Flow	25.0 l/h
Flow max	12.5 l/h
Limit	100 %
Pres. Alm	05.0 Bar
Pres. Comp	Off

Change by pressing and confirm by pressing

Auto: If the pump has a pressure sensor connected, by selecting this option the pump will keep the flow unchanged even if the working pressure changes.

Manual (MAN): If the pump does not have a pressure sensor, but the working pressure is constant, the pressure value can be entered manually so that the pump adjusts to the nominal flow value.




Change by pressing ▲ ▼ and confirm by pressing START STOP

With no compensation (OFF): The pump flow will be as shown in the curves on page 8.

6.2.3.2 Units

Select the units for flow, pressure and proportionality





6.2.3.3 Flowmeter

For a correct water flow reading, the flowmeter constant (volume/pulse or pulses/volume) must be entered. Previously select the type of flowmeter for low or high frequency.

Low frequency: for water meters with low frequency outputs (0.005 Hz to 30 Hz). The constant is expressed in volume/pulse (litres/pulse; gallons/pulse).



High frequency: for flowmeters with high frequency outputs (1 to 300 Hz). The K-factor constant is expressed in pulses/volume (pulses/litre; pulses/gallon).




TIME Q=0, Time interval (seconds) between two pulses to consider zero flow.


6.2.3.4 Lock code

Blocks access to the equipment configuration, allowing the pump to start and stop. When the access code is 0000 (default value), the lock is disabled.






Press for 3 seconds to enter the code and unlock the pump



Enter the code starting with the units (from right to left).
Change values by pressing and validate by pressing


6.2.3.5 ModBus




The pump can be controlled via the RS485 serial port and a ModBus RTU protocol. See the complete ModBus manual.

- Bus: Rs485
- Communication: half-duplex A, B & GND
- baud rate: 9600
- Data bits: 8
- Parity: None
- Stop bits: 1
- Hardware handshake: No
- Character time out: 20 ms
- Time out message end: 100 ms


Important: If an RS232RS485 or similar type converter is required, make sure that the signal emitted does not produce an echo.




Change by pressing and confirm by pressing



Change by pressing and confirm by pressing



Change by pressing and confirm by pressing



Change by pressing and confirm by pressing


6.2.4 Inputs/outputs

6.2.4.1 Pressure input

Calibration of the 4-20 mA pressure transducer input.

x2





CONFIGURATION

PUMP CALIBRATION
DOSING MODE
SET UP
IN/OUT

INPUTS
PRESSURE
FLOW DETECTOR

OUTPUTS
PULSES
4-20mA

PRESSURE INPUT

4 mA 000.0 bar
20 mA 000.0 bar

Enter the pressure value corresponding to 4 mA
Change by pressing ▲ ▼ and confirm by pressing START STOP

PRESSURE INPUT




4 mA 000.0 bar
20 mA 020.0 bar

Enter the pressure value corresponding to 20 mA
Change by pressing ▲ ▼ and confirm by pressing START STOP

6.2.4.2 Flow detector

The flow detector is an accessory that allows the pulses of the supplied flow to be monitored.

x2

CONFIGURATION

PUMP CALIBRATION
DOSING MODE
SET UP
IN/OUT

INPUTS
PRESSURE
FLOW DETECTOR

OUTPUTS
PULSES
4-20mA

FLOW DETECTOR IN

Strokes Pump 010




Enter the number of pump cycles during which no pulse is detected for the alarm to be activated.

Change by pressing ▲ ▼ and validate by pressing START STOP

6.2.4.3 Pulse output

Configuration of the pulse output for monitoring or activation of a second pump.

x2

CONFIGURATION

PUMP CALIBRATION
DOSING MODE
SET UP
IN/OUT



INPUTS
PRESSURE
FLOW DETECTOR

OUTPUTS
PULSES
4-20mA

PULSE OUTPUT

Out = Pulse In

Set whether the pulse output is the same as the pulse input.
With this option a second Dostec AC can be controlled by the same flowmeter in proportional mode (%).





Enter the volume of product dispensed for each product.
Change by pressing ▲ ▼ and confirm by pressing START STOP

With this option another device can receive the dosed volume. Review 5.5.4 for connections.


6.2.4.4 4-20 mA output

4-20 mA output for log or monitoring.



Set whether the pulse output is the same as the pulse input.


Change by pressing ▲ ▼ and confirm by pressing START STOP




Set % flow for 4 mA output
Set % flow for 20 mA output

Change by pressing ▲ ▼ and confirm by pressing START STOP


6.2.5. Mantenimiento



In the Maintenance menu, the status of components subject to wear can be viewed using the status bars.





A warning will appear on the main screen at the end of the useful life of a component.



The status bars in the maintenance menu show the remaining life of each component and display a ! when the bar VAC, with this being the recommended time to replace the component.

You can view the cycles completed by selecting each component. A negative cycle value indicates that it has exceeded the maintenance interval.




When replacing a component that has reached the end of its useful life, the cycle counter must be set to zero by using the YES option.

6.3 ALARMS


In the event of an alarm, the corresponding icon will flash on the main screen. If the cause of the alarm disappears the icon will remain steady. To erase the alarm icon, it is necessary to stop and start the pump using the "ENT" key. The security time is 5 seconds before any alarm is activated.

6.3.1 Level alarm 1


Low level pre-warning according to Level 1 input. Automatic reset (see connection 4.2).



Activate or deactivate the alarm by pressing and confirm by pressing .




Activate or deactivate the Alarm Relay output, when the unit is in alarm, by pressing and confirm by pressing .



Activate or deactivate, stop the pump when the alarm goes off, by pressing and validate by pressing .

6.3.2 Level alarm 2

Low level alarm according to Level 2 input. Automatic reset (see connection 4.2).





Activate or deactivate the alarm by pressing and confirm by pressing



Activate or deactivate the Alarm Relay output, when the unit is in alarm, by pressing and confirm by pressing




Activate or deactivate, stop the pump when the alarm goes off, by pressing and validate by pressing


6.3.3 Flow fault alarm

Dosing flow detector alarm.


See section 4.2.4.2 (Configuration/Inputs/Flow Detector)



Activate or deactivate the alarm by pressing and confirm by pressing



Activate or deactivate the Alarm Relay output, when the unit is in alarm, by pressing and confirm by pressing



Activate or deactivate, stop the pump when the alarm goes off, by pressing and validate by pressing

6.3.4 Diaphragm leakage alarm

Diaphragm leakage detection alarm for electrically conductive liquids (min. 0.05 ms).

x3

x3

DIAPHRAGM LEAKAGE

Alarm	OFF
Relay out	OFF
Stop pump	OFF

Activate or deactivate the alarm by pressing and confirm by pressing

DIAPHRAGM LEAKAGE

Alarm	ON
Relay out	OFF
Stop pump	OFF

Activate or deactivate the Alarm Relay output, when the unit is in alarm, by pressing and confirm by pressing

DIAPHRAGM LEAKAGE

Alarm	ON
Relay out	ON
Stop pump	OFF

Activate or deactivate, stop the pump when the alarm goes off, by pressing and validate by pressing

6.3.5 Overpressure alarm

Overpressure detection alarm. Automatic reset.

x3

x4

OVER PRESSURE


Alarm	OFF
Relay out	OFF
Stop pump	OFF

Activate or deactivate the alarm by pressing and confirm by pressing

OVER PRESSURE

Alarm	ON
Relay out	OFF
Stop pump	OFF

Activate or deactivate the Alarm Relay output, when the unit is in alarm, by pressing and confirm by pressing






Activate or deactivate, stop the pump when the alarm goes off, by pressing and validate by pressing


6.4 MONITOR

6.4.1 Real time

Real-time working parameters



6.4.2 Counters



COUNTERS

Tot. St.	27136	Total cycles
Part. St.	2971	Cycles since last reset
Part. Vol.2		Volume since last reset
Total(h)	46	Total operating time (hours)

START STOP

COUNTERS

Sh. circ.	0	Short circuit alarms
Over load	32	Overload alarms
Over temp	0	High temperature alarms
Th. Shdwn	0	High temperature alarms (chip)
Load open	3	Motor connection fault alarms
Volt range	0	Input voltage alarms

START STOP

RESET COUNTERS

ENT.. = YES
ESC.. = NO

Press **START STOP** to reset the cycle and volume counters or **START STOP** not to reset them

6.4.3 Info Unit

x4

25.0 l/h

MODE

000 %

000

x2

MONITOR

REAL TIME COUNTERS
INFO UNIT

START STOP

INFO UNIT

55-001 →

Serial N.	1000	Unit code
Flow l/h	1.50	Serial number
Press Ba	16.0	Nominal pump flow (l/h or GPH)
Stk/min	0.50	Maximum pressure (bar or psi)
		Cycles/min


START STOP

INFO UNIT


→

Vol/St ml	00.505	Cycle volume
Gear	4.85	Reducer
K. Calib	100	Calibration factor
HW version	4204	Hardware version
SW version	5.07	Software version

7 DOSMART BC USE AND CONFIGURATION



LCD SCREEN DESCRIPTION




7.1 OPERATING MODES

The DOSMART BC pump offers three operating modes, which can be selected using the buttons on the front panel:

Mode Selection:

To change the mode:

1. Press  or  to scroll through the available modes.
2. Press  to confirm the selection.




To return to the mode selection menu, press and hold  for 2 seconds.


7.1.1 Manual Mode

In this mode, the user can manually adjust the dosing flow rate.

This mode allows simple and direct control, ideal for quick adjustments or testing.



Use the  or  buttons to change the operating percentage (e.g. 0–100%).



Press  to start or stop the pump.

7.1.2 Pulse Mode (X:Y)

This mode sets the ratio between input pulses (X) and pump cycles (Y).

The pump begins dosing upon receiving the second pulse and automatically adjusts its speed based on the interval between pulses.


If the unit operates outside its pulse range, the alarm "PULSE RANGE" will be triggered. If the pulse frequency is too low, the pump will stop; if it exceeds maximum capacity, the pump will run at full speed and any excess pulses will be ignored.



Select the X:Y mode from the main menu using \blacktriangle or \blacktriangledown , and confirm with START/STOP . Press any button to enter the mode configuration.




Use \blacktriangle or \blacktriangledown to adjust each value. Press START/STOP to confirm and move between parameters or to finish. The value range is from 1 to 60,000.



Once configured, press START/STOP to start or stop the pump.

The pump will stop when the time since the last pulse is twice the interval between previous pulses (see graph).



Proportional Configuration (% , ppm)

For configuring a very specific proportionality in % or ppm, it is recommended to use the X:Y calculator accessed via the QR code (also available on the itc.es website).



To obtain the X and Y values, enter the pump data, counter information, and desired proportion into the calculator. The tool will automatically generate the necessary parameters to configure proportional dosing.

DOSmart BC X/Y Parameter Calculator

Pump Parameters


Flowmeter or Counter

Desired Ratio

Calculate X and Y ↓

7.1.3 Check Info Mode

This mode allows viewing technical and status information of the unit. Data is displayed sequentially on the screen and is read-only.



La información mostrada incluye:


- Remote control status
- Internal temperature
- Power supply voltage
- Presence of input pulses
- Product level status
- Installed firmware version
- Unit serial number

This mode is useful for diagnostics, technical support, and parameter validation during operation.

8 Special functions (AC & BC)

8.1 Remote activation

An external remote control can be used to start and stop the pump via volt-free contact at positions 17 - 18.




When the contact is closed (RUN) the pump may be run manually via the ENT key. After stopping the pump manually via the keypad, it is necessary to reset the Remote Input (open and close) to start the pump again remotely.



9 START-UP AND REGULATION

- ⚠ FIXING: Check that the pump is properly secured
- ⚠ HYDRAULIC CIRCUIT CHECK: Check that all valves are open, and that the bleed and relief valve outlets are diverting the liquid to a container
- ⚠ PUMP CHECK: Make a visual/auditory check of the correct operation of the pump.
- ⚠ PRIMING: To facilitate pump priming, open the priming valve.
- ⚠ OVERPRESSURE PROTECTION: Adjust the safety, overpressure or pressure relief valve to the desired pressure to protect the installation, while never exceeding the nominal pressure of the pump.

10 MAINTENANCE

SPARE PARTS






PARTS LIST

CODE	DESCRIPTION	QUANTITY
28090	Power supply 240 Vac 24 Vac	1
29620	AC control PCB plate	1
44303	7.5x2.5 FPM O-ring	4
54202	DOSmart BC Control PCB	1
54662	DOSmart BC Lexan Cover	1
55103	Dosmart shaft	1
55105	Dosmart spring	1
55-109	Dosmart cam	1
55110-P//F	Diaphragm cylinder D50	1
55111-P/F	D50 diaphragm base	1
55116	Dosmart Cam spring stop	1
55118-P//F	D50 diaphragm base	1
55119	Dosmart Machined mechanism support	1
55120	Dosmart bellows	1
55148	Dosmart Hydraulics housing	1
55149	Dosmart Electronics housing	1
55150	Front Dosmart Electronics housing	1
55154	Dosmart Shaft bushing	1
55200	D50 diaphragm	1
55202	Lexan DOSMART	1
55300	Allen bolt M2,5x3 DIN 912	2
55302	Fitting washer 12x18x1 DIN 988	1
55303	D15 DIN 471 safety ring	1
55304	Allen screw M4x4 DIN 913	1
55305	Bearing 6201-2RSH (12x32x10)	2
55306	Bearing 61909-2RS (45x68x12)	2
55310	Bolt 4x20 E0210 A2	6
55601	Dosmart Hall Sensor PCB	1
55605	Dosmart power plate PCB	1
55606	Power Supply 240 Vac to 24 Vac	1
55655-M12	3 pin male panel connector	1
55-800-P//F	Double ball suction valve L ¾ 4-6-10	1
55-801-P//F	Delivery valve L ¾ 4-6-10	1
55-835-P/F	Dosmart priming valve L ¾	1
55309	Gasket 2 mm EPDM25	2
59300	Bolt M4x8 DIN965 A2	2
59309	Bolt 4x16 E0210 A2	6
59353	Cable gland M16 white	3
60304	Bolt M4x8 DIN912 A4	4
62318	Ferrite D6x3 sxp magnet	1
63212	Allen bolt M5x12 DIN912 A4-80	1
63213	Motor washer F5 18x5x2.5	1
63333	Screw M8x80 DIN912 A2	4
67100	D69 diaphragm	1
67104.2-P/F	D69 diaphragm base	1
67105.2-P/F	D69 Diaphragm cylinder	1
73615-M12	4-20 mA hose cable + connector	1
73654-M2	150mm flow hose cable	1

6x12 VALVES (60 l/h max.)


Discharge

55-801-P



Suction


55-800-P



Pipes	4x6	6x8	6x12	10x12
Flanges	55826-P	60878.1-P	60877.1-P	
Pins	55825-P	55827-P	55829-P	

PRIMING VALVE

55-835-P (60l/h máx.)





Before any maintenance operation check:

The pump is stopped and disconnected from the power supply.

There is no pressure inside the head or in the discharge pipe. It is recommended to empty the head before opening it.

Maintenance personnel should use the appropriate means of protection for handling the liquid being dosed.

PERIODIC MAINTENANCE:

Check the condition of the suction filter once a month.

Check the condition of the valves every 3 months or 1000 hours

We recommend periodically circulating clean water through the dosing pump (coinciding for example with the emptying of the tank), in order to remove any precipitated remains from inside the cylinder or in the suction and discharge pipes.

In the event of using highly corrosive liquids, it is recommended to double the frequency of the checks.

TROUBLESHOOTING: POSSIBLE CAUSE AND SOLUTION


PROBLEM	CAUSE	SOLUTION
Pantalla Apagada	<ul style="list-style-type: none"> - No voltage - The thermomagnetic circuit breaker has tripped 	<ul style="list-style-type: none"> - Check the input voltage with a voltmeter - Check for short circuit
Short Circuit	<ul style="list-style-type: none"> - Unstable input voltage 	Install a voltage stabilizer
 AL-1	<ul style="list-style-type: none"> - Bad contact in power connector 	<ul style="list-style-type: none"> - Check the electronics power connectors
	<ul style="list-style-type: none"> - Internal short circuit 	<ul style="list-style-type: none"> - Contact ITC technical service
	<ul style="list-style-type: none"> - Blocking of the pump due to overpressure or mechanism fault 	<ul style="list-style-type: none"> - Check for any closed valve in the pump delivery piping - Check that the mechanism rotates freely
Overt Temp / Thermal Shutdown	<ul style="list-style-type: none"> - Ambient temperature higher than allowed (45 °C) 	<ul style="list-style-type: none"> - Condition the work area to ensure temperature conditions within the tolerated range
 AL-2	<ul style="list-style-type: none"> - The pump is working with overpressure 	<ul style="list-style-type: none"> - Check that the line pressure is lower than the maximum allowable pressure of the unit
	<ul style="list-style-type: none"> - Incorrectly dimensioned delivery pipe 	<ul style="list-style-type: none"> - Shorten the delivery pipe or increase its diameter
Over Load	<ul style="list-style-type: none"> - The pump is working with overpressure 	<ul style="list-style-type: none"> - Check that the line pressure is lower than the maximum allowable pressure of the unit
 AL-3	<ul style="list-style-type: none"> - Incorrectly dimensioned delivery pipe 	<ul style="list-style-type: none"> - Shorten the delivery pipe or increase its diameter
	<ul style="list-style-type: none"> - Connection fault between the motor and the electronics board 	<ul style="list-style-type: none"> - Check the connections between motor and electronics
Out of Range Voltage	<ul style="list-style-type: none"> - Supply voltage outside the allowed range 	<ul style="list-style-type: none"> - Correct the input voltage so that it is within the allowed range
 AL-5		

PROBLEM	CAUSE	SOLUTION
Motor runs but pump does not inject or dosing is lower than nominal	- Pump not primed	- Prime the pump by opening the priming valve or filling the head with the liquid to be injected
	- Dirty or damaged suction or delivery valve	- Clean or change valves
	- Dirty suction filter	- Clean filter
	- Air enters the suction pipe	- Check tightness of connection points
	- Cavitation in suction	- Increase pipe diameter. - Reduce the suction pipe length. - Reduce speed by using a variator. - Use a less viscous liquid.
Pump drips liquid from bottom orifice of cylinder	- Damaged diaphragm	- Change diaphragm





DOSMART BC UNIQUE ALARMS

PROBLEM	CAUSE	SOLUTION
Product Level  AL-6	- Product dosing level low	- Refill product tank
Pulse Range (flashing)	- Input pulse frequency out of allowed range	- Check input wiring - Inspect flowmeter or pulse emitter - Adjust X:Y ratio to compatible values

WIRING



DOSMART AC BOARD



- B**
- ① +
 - ② +24Vdc
 - ③ -
- C**
- ① REMOTE
 - ② REMOTE
 - ③ LEVEL 1
 - ④ LEVEL 2
 - ⑤ COMMON

External quick connectors

CE DECLARATION OF CONFORMITY



I.T.C. S.L.
Vallès, 26
Polígono Industrial Can Bernades-Subirà
08130 Santa Perpètua de Mogoda

Declares that all models of DOSmart AC products identified with serial number and year of manufacture comply with Machinery Directive 2006/42/EC, Low Voltage Directive D2014/35/EU and Electromagnetic Compatibility Directive D2014/30/EU, provided that the installation, use and maintenance are carried out in accordance with current regulations and following the instructions in the instruction manual.

Xavier Corbella
Manager

 WARRANTY	<p>I.T.C. S.L. guarantees the product specified in this document, for a period of 1 year from the date of purchase, against all manufacturing or material defects, provided that installation, use and maintenance of the equipment are correct.</p> <p>The equipment must be sent, free of charge, to our workshop or I.T.C. S.L.-accredited technical service and will be returned cash on delivery.</p> <p>The equipment must be accompanied by the warranty document, with the purchase date and stamp of the establishment where purchased, or a photocopy of the purchase invoice.</p>	
	<p>MODEL</p> <input style="width: 90%; height: 20px;" type="text"/>	<p>Date of purchase and stamp of the establishment where purchased</p> <p>DATE: <input style="width: 80%; height: 20px;" type="text"/></p>
	<p>SERIAL No.</p> <input style="width: 90%; height: 20px;" type="text"/>	



A VERDER COMPANY

C/ VALLÈS, 26 P. I. CAN BERNADES-SUBIRÀ
P.O. BOX 60
08130 SANTA PERPÈTUA DE MOGODA
BARCELONA (SPAIN)
T. (+34) 935 443 040 / SAT.ITC@VERDER.COM



Empresa certificada por



Safety
Functionality
Quality
ISO 9001:2015
ISO 14001:2015



www.tuv.com
ID 9105017955