

# MF: CHECKING OIL LEVEL

- 1-Remove the screw-top
  - 2-Introduce the rod
  - 3-Take out the rod and check the oil level.
- (Recommended oil: SAE 80W/90 GEAR BOX OIL)

