

- 1-.Remove the screw-top
 - 2-.Introduce the rod
 - 3-.Take out the rod and check the oil level.
- (Recommended oil: SAE 80W/90 GEAR BOX OIL)

